

# CALCIUMWASH

## Deglazer wash for roller and blankets

### KEY CHARACTERISTICS

- Specific density: 1,055 g/ml
- Suited for NBR rubber
- For sheetfed, heatset and coldset application
- pH value: 2,5
- Total elimination of calcium deposits on ink rollers

### PACKAGING

10L jerrycan  
12 x 1L plastic bottle

### INSTRUCTIONS FOR USE

Run off ink using conventional washing fluid. Apply the cleaner to the rollers and let run up to 5 minutes at normal washing speed. Set the doctor blade and rinse with plenty of water

### TRANSPORT & STORAGE

Protect against extreme weather conditions.

Do not store at temperature above 35 °C or below -10 °C.

Take all necessary precautions to avoid environmental pollution due to accidental leakage.

### FEATURES AND BENEFITS

#### **Free of naphthenes, aromatic and chlorinated hydrocarbons**

- Health and environmental friendly

#### **Strong cleaning action**

- Economical in use
- Less standstills

Version 1.0, state 19/09/2011 - All data contained in this technical information sheet is based upon lab tests and practical experience. The user is aware that user specific circumstances may influence the results. This technical information sheet is made for information purposes only and it does not constitute a warranty or guarantee in relation to the correctness or completeness of the data. Errors, omissions and literal mistakes excepted, subject to modifications at any time. The user acknowledges that the data contained herein is only effective as long as no updated technical information sheet is issued which replaces and supersedes any former version of this technical information sheet.